


# INSTALLATION OF SPACESLIDE ROOM DIVIDER SYSTEM




**Important: Ensure there are no water pipes or electrical cables in the area of the installation**

The system is supplied complete with outer frame consisting of twin or single top track, twin or single bottom track and twin or single wall uprights together with door leaves.


The outer frame profiles are supplied approximately 100mm oversize for cutting down on site to allow accurate installation to aperture on sites. Adjustment of +/- 5mm on designed size can be made to the outer frame.


The installation sequence for the outer frame is bottom track cut to order size. Top track is fitted between the outer stiles therefore the cutting size is bottom track size minus 38mm. The outer stiles are installed on top of the bottom track and run full height – cutting size is order size minus 8mm.

### Twin Divider System




### Single Divider System



**1****Step 1****Standard twin track system**

Trim the outer frame to fit the opening (this should not be more or less than 5mm from the nominal manufactured size). Mark the profiles with a set square and cut using a hacksaw as accurately as possible. To assist when cutting insert timber blocks into top track for support, as illustrated.

**2****Step 2****Installing the bottom track**


Drill 5mm clearance holes in the centre of the profile, 150mm from each end and at 600mm centres.

Place track in position, use a spirit level to ensure flat and secure to structure – do not over tighten as this may deform the track.


**3****Step 3****Uprights**

Place outer upright in position. If fixing to brickwork mark the position of the fixing holes central on the wall and drill 5mm clearance holes in centre of the profile cavity, 150mm from each end and at 600mm centres.

Using a spirit level ensure the profile is plumb in both directions and secure to structure.



# 4




## Step 4

### Installing top track

Drill 5mm clearance holes in either channel. Place in position between outer uprights and secure.

# 5



## Step 5

### Installing doors


Tilt the door as shown and insert the top rail into the rear channel. Load the rollers onto the rear track. Take care not to scratch the bottom track. Repeat the process with the second door using the front channel and front bottom track.


For multidoor systems alternate doors on track.

# 6

## Step 6

**Vertical adjustment of doors** – Use a posidrive screwdriver to raise or lower the roller via the access hole in the bottom of the door stile.






**Single track system –**

Used when a single door is required to seal on opening or bi-parting doors on the same track.

**Multi-track system –**

The single track system can interlock with twin track to give a three track or four track system to allow stacking doors to the end.



Pushing back the boundaries of space

PORTICO Midlands Limited, Middlemore Lane, Aldridge, Walsall, West Midlands WS9 8SP

T: 01922 743211 - F: 01922 743513 - E: sales@porticomidlands.co.uk

[www.spaceslide.co.uk](http://www.spaceslide.co.uk)